

COOKING/SMOKING/HOLDING PROCEDURES — MANUAL OVENS

1. PREPARE OVEN FOR COOKING


- A. Insert and adjust the required number of shelves inside the cooking cavity. Insert each shelf with curved edge of the shelf toward the back of the oven.
- B. Adjust the inside door vents as indicated in the individual cooking procedure selected.
- C. Insert drip pan on the bottom surface of the oven cavity.

2. PREHEAT OVEN

- A. Turn power switch “**ON**”.
- B. Set “**HOLD**” thermostat to required holding temperature.
- C. Set “**COOK**” thermostat to required cooking temperature.
- D. Turn timer knob clockwise to activate “**COOK**” thermostat.
- E. Allow oven to preheat 45 minutes.

3. PREPARE PRODUCT FOR COOKING

- A. Refer to individual cooking instructions.

WARNING	
	<p>THE USE OF IMPROPER MATERIALS FOR THE SMOKING FUNCTION COULD RESULT IN DAMAGE, HAZARD, EQUIPMENT FAILURE OR COULD REDUCE THE OVERALL LIFE OF THE OVEN.</p> <p>DO NOT USE SAWDUST FOR SMOKING.</p> <p>DO NOT USE WOOD CHIPS SMALLER THAN THUMBNAIL SIZE.</p>

4. LOAD PRODUCT ON SHELVES

- A. Refer to individual cooking instructions. Do **NOT** overload the oven.
- B. Most meat products are cooked directly on wire shelves. For many products, the use of pans is not recommended.

5. LOAD WOOD CHIPS

- A. Take one container load of dry wood chips and soak the chips in water for 5 minutes.
- B. Shake excess water off wood chips.
- C. Remove Wood Chip Container from the interior back panel of the smoker. Place the moistened chips in the Wood Chip Container and replace the container in the oven.

6. CLOSE DOOR

- A. Keep door closed during the cooking and smoking cycle.

7. RESET COOKING TIMER FOR CORRECT NUMBER OF HOURS

- A. To set cooking time, turn the timer knob past the required number of hours then immediately bring it back to the correct setting.
- B. Refer to individual cooking instructions for length of time necessary to cook.
- C. When timer cycles to the “**OFF**” position, the temperature automatically lowers to the selected “**HOLD**” temperature.
- D. The product must remain in the oven, at the selected “**HOLD**” temperature, for the minimum number of hours indicated in the individual cooking instructions.

CONTINUED