


OVEN COMPARTMENT CONTROL PANEL IDENTIFICATION



- 1.** Press oven POWER SWITCH **5** "ON."
 - POWER "ON" INDICATOR SWITCH will illuminate and will remain lit as long as the power switch is in the "ON" position.
- 2.** Set "HOLD" thermostat **2** to required holding temperature.
 - HOLDING INDICATOR LIGHT will illuminate as the holding thermostat calls for heat. This process will continue as long as the Power Switch is in the "ON" position and holding thermostat is activated.
- 3.** Set "COOK" thermostat **3** to required cooking temperature.
- 4.** Activate the "COOK" thermostat to preheat the oven by turning the "COOKING" timer **4** clockwise.
 - COOKING INDICATOR LIGHT and the HOLDING INDICATOR LIGHT will alternately illuminate as each thermostat calls for heat. This process will continue until the cooking timer cycles or is turned to the "OFF" position.

TEMPERATURE GAUGE **1** will indicate the air temperature inside the oven compartment.